



## INTRODUCTION

Please read the entire users guide before using the hub. For the newest version of this guide or for miscellaneous questions, please consult the official representative for the country in which you reside or consult our website [www.last-bikes.com](http://www.last-bikes.com).

**CAUTION** - In the case of non-compliance with these instructions, the function of the product will be impaired, which may lead to injuries with serious consequences, and the loss of the product guarantee.

## INTENTIONAL USE

Last hubs are designed to be used on bicycles only. The hubs are not designed for use on tandems.

## IMPORTANT

- Before every use, check the front hub for play. In such a case, the problem must be repaired before use. If you are not in a position to repair the hub, contact a professional bike mechanic.
- New hubs have a higher rolling resistance than used hubs, because the seals have not yet been bedded in.
- **CAUTION** - Radial lacing on our hubs is not recommended as it may lead to impermissible deformations on the hub flange. Flange breakage is not covered under the warranty in this case. Spokes must cross 3 times.
- Disregarding these instructions will limit the function of the hub and can lead to injury or other severe consequences and the loss of the product warranty.
- Do not use high pressure water jets to clean the hubs.
- Maintenance work and repairs must be carried out by professional bike mechanics or similar qualified persons using the available special tools. For Maintenance work and repair instructions refer to the technical manual which can be downloaded from our website [www.last-bikes.com](http://www.last-bikes.com).

## MAINTENANCE OF THE HUBS

Maintenance of the hub must be carried out at least once a year. When used under extreme conditions (heavy rain, mud, transport in the rain etc.) the hub should be serviced more often. Regular maintenance of the hub helps to ensure a longer life and optimum running performance for years. In the case of exposure to water under excessive pressure (e.g. high-pressure cleaners), water may penetrate into the hub. This may damage the hub. Do not use any solvents or detergents.

## WHEEL BUILDING INFORMATION

spoke hole pattern diameter (PCD)	47,0 mm
spoke hole diameter	2,5 mm
distance flange to center line	35,2 mm
symmetrical (left = right)	

## WARRANTY TERMS

Please visit our website for the latest version of the warranty terms.